

Lecture 5

Thermodynamic Response Functions




Fig. 2.9 A constant-volume bomb calorimeter. The 'bomb' is the central vessel, which is strong enough to withstand high pressures. The calorimeter (for which the heat capacity must be known) is the entire assembly shown here. To ensure adiabaticity, the calorimeter is immersed in a water bath with a temperature continuously readjusted to that of the calorimeter at each stage of the combustion.

Measuring the Change in Internal Energy

Constant volume process

$$\Delta U = q + w$$

Adiabatic process

$$\Delta U = q_v$$

$$(w = 0)$$

$$\Delta U = w$$

$$(q = 0)$$

Estimate q_v with a calorimeter

Estimate w as PV work

The change in temperature, ΔT , of the calorimeter is proportional to the energy that the reaction releases or absorbs as heat. Therefore, by measuring ΔT we can determine q_v and hence find ΔU . The conversion of ΔT to q_v is best achieved by calibrating the calorimeter using a process of known energy output and determining the calorimeter constant, the constant C in the relation

$$q = C\Delta T$$

A note on heat-capacity and specific heat (capacity)
(Response Function)

Heat capacities are extensive properties: 100 g of water, for instance, has 100 times the heat capacity of 1 g of water (and therefore requires 100 times the energy as heat to bring about the same rise in temperature). The **molar heat capacity at constant volume**, $C_{V,m} = C_V/n$, is the heat capacity per mole of substance, and is an intensive property (all molar quantities are intensive). Typical values of $C_{V,m}$ for polyatomic gases are close to $25 \text{ J K}^{-1} \text{ mol}^{-1}$. For certain applications it is useful to know the **specific heat capacity** (more informally, the 'specific heat') of a substance, which is the heat capacity of the sample divided by the mass, usually in grams: $C_{V,s} = C_V/m$. The specific heat capacity of water at room temperature is close to $4.2 \text{ J K}^{-1} \text{ g}^{-1}$. In general, heat capacities depend on the temperature and decrease at low temperatures. However, over small ranges of temperature at and above room temperature, the variation is quite small and for approximate calculations heat capacities can be treated as almost independent of temperature.



James Prescott Joule

Variation of Internal Energy U with Volume

- Variation with volume at constant temperature $\left(\frac{\partial U}{\partial V}\right)_{T,N}$





Fig. 2.24 For a perfect gas, the internal energy is independent of the volume (at constant temperature). If attractions are dominant in a real gas, the internal energy increases with volume because the molecules become farther apart on average. If repulsions are dominant, the internal energy decreases as the gas expands.

Joule's experiment

Isothermal expansion of an ideal gas **against zero pressure**

Observation: $dT = 0$

$\delta w = 0$; $\delta q = 0$

$$U = U(T, V)$$

$$du = \left(\frac{\partial u}{\partial T}\right)_V dT + \left(\frac{\partial u}{\partial V}\right)_T dV$$

Response function:- $C_V = \left(\frac{\partial u}{\partial T}\right)_V$ $\pi_T = \left(\frac{\partial u}{\partial V}\right)_T$

Specific heat at const.
volume

Internal
Pressure

$$du = C_V dT + \pi_T dV$$

$$\Delta U = C_V \Delta T + \pi_T \Delta V$$

Now, as $U = U(T, V)$

Following cyclic rule, we can write,

$$\left(\frac{\partial u}{\partial V}\right)_T \left(\frac{\partial V}{\partial T}\right)_u \left(\frac{\partial T}{\partial u}\right)_V = -1$$

Hence, $\left(\frac{\partial u}{\partial V}\right)_T = - \left(\frac{\partial T}{\partial V}\right)_u \left(\frac{\partial u}{\partial T}\right)_V$

$$\pi_T = - \mu_J C_V$$

$$\mu_J = \left(\frac{\partial T}{\partial V}\right)_u \Rightarrow \text{Joule's coefficient}$$

Response Functions

$$\left(\frac{\partial U}{\partial T}\right)_p = \pi_T \left(\frac{\partial V}{\partial T}\right)_p + C_V$$

It is usually sensible in thermodynamics to inspect the output of a manipulation like this to see if it contains any recognizable physical quantity. The partial derivative on the right in this expression is the slope of the plot of volume against temperature (at constant pressure). This property is normally tabulated as the **expansion coefficient**, α , of a substance, which is defined as

$$\alpha = \frac{1}{V} \left(\frac{\partial V}{\partial T} \right)_p$$

Definition of the expansion coefficient

[2.42]

and physically is the fractional change in volume that accompanies a rise in temperature. A large value of α means that the volume of the sample responds strongly to changes in temperature. Table 2.9 lists some experimental values of α . For future reference, it also lists the **isothermal compressibility**, κ_T (kappa), which is defined as

$$\kappa_T = -\frac{1}{V} \left(\frac{\partial V}{\partial p} \right)_T$$

Definition of the isothermal compressibility

[2.43]

The isothermal compressibility is a measure of the fractional change in volume when the pressure is increased by a small amount; the negative sign in the definition ensures that the compressibility is a positive quantity, because an increase of pressure, implying a positive dp , brings about a reduction of volume, a negative dV .

Table 2.9* Expansion coefficients (α) and isothermal compressibilities (κ_T) at 298 K

	$\alpha/(10^{-4} \text{ K}^{-1})$	$\kappa_T/(10^{-6} \text{ bar}^{-1})$
Benzene	12.4	90.9
Diamond	0.030	0.185
Lead	0.861	2.18
Water	2.1	49.0

* More values are given in the *Data section*.

Example 2.8 Calculating the expansion coefficient of a gas

Derive an expression for the expansion coefficient of a perfect gas.

Method The expansion coefficient is defined in eqn 2.42. To use this expression, substitute the expression for V in terms of T obtained from the equation of state for the gas. As implied by the subscript in eqn 2.42, the pressure, p , is treated as a constant.

Answer Because $pV = nRT$, we can write

$$\alpha = \frac{1}{V} \left(\frac{\partial(nRT/p)}{\partial T} \right)_p = \frac{1}{V} \times \frac{nR}{p} \frac{dT}{dT} = \frac{nR}{pV} = \frac{1}{T}$$


The higher the temperature, the less responsive is the volume of a perfect gas to a change in temperature.

Self-test 2.9 Derive an expression for the isothermal compressibility of a perfect gas. $[\kappa_T = 1/p]$

Introducing Enthalpy

- Heating at constant volume
- $\Delta U = q_V$


Schematic diagram



$$q_V = Q = m C_V \Delta T$$

- Heating at constant pressure

Schematic diagram




$$q_p = Q = m C_p \Delta T$$

Enthalpy and heat

- $H = U + pV$ and $\Delta H = Q_p$

Enthalpy changes are measured using

- isobaric calorimeter
- differential scanning calorimeter
- adiabatic flame calorimeter



- Properties of H :

✓ **state function**, $\Delta H = H_2 - H_1$ for change in state from 1 to 2

✓ **exact differential**

$$dH = d(U + pV) = dU + p dV + V dp$$

✓ **For constant pressure processes,**

$$dp = 0 \Rightarrow dH = dU + p dV = \delta q_p \text{ (Using 1st law)}$$

✓ **For finite isobaric process**

$$\int_1^2 dH = \Delta H = H_2 - H_1 = \int_1^2 \delta q_p = Q_p$$

$$\Delta H = Q_p$$

Variation of Enthalpy with Temperature & Pressure

By definition, $dH = dU + d(pV)$

For an ideal gas, $pV = nRT$

$$\therefore dH = dU + RdnT$$

For an ideal gas undergoing isothermal change in state (e.g. a gas phase chemical reaction at constant T),

$$dH = dU + RTd(n) \Rightarrow \Delta H = \Delta U + (\Delta n)RT$$

In general, for a closed system

$$H = H(p, T)$$

$$dH = C_p dT + \left(\frac{\partial H}{\partial p} \right)_T dp$$

Variation with temperature at constant pressure

$$C_p = \left(\frac{\partial H}{\partial T} \right)_p \quad dH_p = C_p dT \quad \Delta H_p = Q_p = C_p \Delta T$$

Variation with pressure at constant temperature

$$H = H(p, T)$$


$$\therefore \left(\frac{\partial H}{\partial p} \right)_T \left(\frac{\partial p}{\partial T} \right)_H \left(\frac{\partial T}{\partial H} \right)_p = -1$$

$$\therefore \left(\frac{\partial H}{\partial p} \right)_T = - \left(\frac{\partial T}{\partial p} \right)_H \left(\frac{\partial H}{\partial T} \right)_p = -\mu_{JT} C_p$$

$$\mu_{JT} = \left(\frac{\partial T}{\partial p} \right)_H$$

Jule Thompson Coefficient

Joule Thompson Experiment and Effect



$$\text{For this experiment, } q = 0 \Rightarrow \Delta U = U_2 - U_1 = w$$

Observation of the Joule–Thomson effect: The analysis of the Joule–Thomson coefficient is central to the technological problems associated with the liquefaction of gases. We need to be able to interpret it physically and to measure it. As shown in the following Justification, the cunning required to impose the constraint of constant enthalpy, so that the process is isenthalpic, was supplied by Joule and William Thomson (later Lord Kelvin). They let a gas expand through a porous barrier from one constant pressure to another and monitored the difference of temperature that arose from the expansion (Fig. 2.26). The whole apparatus was insulated so that the process was adiabatic. They observed a lower temperature on the low pressure side, the difference in temperature being proportional to the pressure difference they maintained. This cooling by isenthalpic expansion is now called the Joule–Thomson effect.

$$\text{For this experiment, } q = 0 \Rightarrow \Delta U = U_2 - U_1 = w$$

$$w = -p_1(0 - V_1) - p_2(V_2 - 0) = p_1V_1 - p_2V_2$$

$$\text{Thus, } U_2 - U_1 = p_1V_1 - p_2V_2 \Rightarrow U_2 + p_2V_2 = U_1 + p_1V_1$$

$$\therefore H_2 = H_1$$

Isenthalpic expansion of a gas from a region of constant high pressure to a region of **constant low pressure** through a porous plug

$$\mu_{JT} = \left(\frac{\partial T}{\partial p} \right)_H \approx \frac{\Delta T}{\Delta p} \text{ under isenthalpic condition}$$

Joule Thompson Effect and Inversion Temperature




Fig. 2.30 The sign of the Joule–Thomson coefficient, μ , depends on the conditions. Inside the boundary, the blue area, it is positive and outside it is negative. The temperature corresponding to the boundary at a given pressure is the ‘inversion temperature’ of the gas at that pressure. For a given pressure, the temperature must be below a certain value if cooling is required but, if it becomes too low, the boundary is crossed again and heating occurs. Reduction of pressure under adiabatic conditions moves the system along one of the isenthalps, or curves of constant enthalpy. The inversion temperature curve runs through the points of the isenthalps where their slope changes from negative to positive.

The inversion temperature of a gas is the temperature below which the gas exhibits the Joule-Thomson effect (cooling upon expansion at constant enthalpy) and above which it heats up upon expansion.

Gas Inversion temperature

He	40 K
H ₂	202 K
Ne	231 K
N ₂	621 K
Air	673 K
O ₂	764 K
CO ₂	1500 K

N₂ and O₂ will cool upon expansion at room temperature, but He, H₂ and Ne will warm upon expansion at room temperature.

Homework



For a van der Waals gas,

$$\mu_{JT} = \frac{1}{C_p} \left(\frac{2a}{RT} - b \right)$$

Understand the molecular explanation as taught in the class

Thermodynamic Response Functions

These are **measurable quantities** that can be obtained from experiments involving variation of p, V, T of closed systems

Response function	Definition
Specific heat at constant volume	$C_V = \left(\frac{\partial U}{\partial T} \right)_V$
Specific heat at constant pressure	$C_p = \left(\frac{\partial U}{\partial T} \right)_p$
Isobaric expansion coefficient	$\alpha = \frac{1}{V} \left(\frac{\partial V}{\partial T} \right)_p$
Joule coefficient	$\mu_J = \left(\frac{\partial T}{\partial V} \right)_U$
Joule Thomson coefficient	$\mu_{JT} = \left(\frac{\partial T}{\partial p} \right)_H$

Expression of $\bar{c}_p - \bar{c}_v$:

We have by definition, $\bar{c}_p - \bar{c}_v = \left(\frac{\partial H}{\partial T}\right)_P - \left(\frac{\partial U}{\partial T}\right)_V$

But, $H = U + PV$ or $\left(\frac{\partial H}{\partial T}\right)_P = \left(\frac{\partial U}{\partial T}\right)_P + P \left(\frac{\partial V}{\partial T}\right)_P$

Hence, $\bar{c}_p - \bar{c}_v = \left(\frac{\partial U}{\partial T}\right)_P - \left(\frac{\partial U}{\partial T}\right)_V + P \left(\frac{\partial V}{\partial T}\right)_P$

But, $U = f(T, V)$ Hence, $du = \left(\frac{\partial U}{\partial T}\right)_V dT + \left(\frac{\partial U}{\partial V}\right)_T dV$

dividing by dT at constant 'P' —

$$\left(\frac{\partial U}{\partial T}\right)_P = \left(\frac{\partial U}{\partial T}\right)_V + \left(\frac{\partial U}{\partial V}\right)_T \left(\frac{\partial V}{\partial T}\right)_P$$

$$\text{or, } \left(\frac{\partial U}{\partial T}\right)_P - \left(\frac{\partial U}{\partial T}\right)_V = \left(\frac{\partial U}{\partial V}\right)_T \left(\frac{\partial V}{\partial T}\right)_P$$

Putting the value, $\bar{c}_p - \bar{c}_v = \left[P + \left(\frac{\partial U}{\partial V}\right)_T \right] \left(\frac{\partial V}{\partial T}\right)_P$

But, thermodynamic equation of state is, $P + \left(\frac{\partial U}{\partial V}\right)_T = T \left(\frac{\partial P}{\partial T}\right)_V$

$$\text{Hence, } \boxed{\bar{c}_p - \bar{c}_v = T \left(\frac{\partial P}{\partial T}\right)_V \left(\frac{\partial V}{\partial T}\right)_P}$$

This is the general expression of $\bar{c}_p - \bar{c}_v$ for any system, ideal or real and is valid also for condensed system.

(a) $\bar{C}_p - \bar{C}_v$ for Ideal Gas: The equation of state is, $PV = nRT$
 & for 1 mole, $PV = RT$

Hence, $\left(\frac{\partial P}{\partial T}\right)_V = \frac{R}{V}$ & $\left(\frac{\partial V}{\partial T}\right)_P = \frac{R}{P}$ so, $\boxed{\bar{C}_p - \bar{C}_v = R}$ for ideal gas

(c) $\bar{C}_p - \bar{C}_v$ for VDW Gas: The equation of state for 1 mole is -

$$\left(P + \frac{a}{V^2}\right)(V-b) = RT$$

$$\text{or, } P = \frac{RT}{V-b} - \frac{a}{V^2} \quad \text{or, } \left(\frac{\partial P}{\partial T}\right)_V = \frac{R}{V-b}$$

Again, the equation -

$$PV - Pb + \frac{a}{V} = RT \quad \text{or, } P\left(\frac{\partial V}{\partial T}\right)_P - \frac{a}{V^2}\left(\frac{\partial V}{\partial T}\right)_P = R \quad \text{or, } \left(\frac{\partial V}{\partial T}\right)_P = \frac{R}{P - \frac{a}{V^2}}$$

$$\text{Therefore, } \bar{C}_p - \bar{C}_v = T \left(\frac{\partial P}{\partial T}\right)_V \left(\frac{\partial V}{\partial T}\right)_P$$

$$= T \times \frac{R}{V-b} \times \frac{R}{P - \frac{a}{V^2}} = \frac{R^2 T}{(V-b) \left(P + \frac{a}{V^2} - \frac{2a}{V^2}\right)}$$

$$= \frac{R^2 T}{(V-b) \left(\frac{RT}{V-b} - \frac{2a}{V^2}\right)} = \frac{R^2 T}{(V-b) \times \frac{RT}{V^2} \left(1 - \frac{2a(V-b)}{V^2 RT}\right)}$$

$$= \frac{R}{\left(1 - \frac{2a}{RTV}\right)} = R \left(1 - \frac{2a}{RTV}\right)^{-1} = R \left(1 + \frac{2a}{RTV}\right) = \left(R + \frac{2a}{TV}\right) \quad \text{Putting } V = \frac{RT}{P}$$

$$\text{We have, } \boxed{\bar{C}_p - \bar{C}_v = R + \frac{2aP}{RT^2}}$$

This shows that for VDW Gas, $\bar{C}_p - \bar{C}_v$ is greater than R .

(d) $\bar{C}_p - \bar{C}_v$ in terms of α and β :

By definition, $\alpha = \frac{1}{V} \left(\frac{\partial V}{\partial T} \right)_P$ and $\beta = -\frac{1}{V} \left(\frac{\partial V}{\partial P} \right)_T$

Therefore, $\bar{C}_p - \bar{C}_v = T \left(\frac{\partial P}{\partial T} \right)_V \left(\frac{\partial V}{\partial T} \right)_P = T \times \frac{\alpha}{\beta} \times \alpha V$

Because, $\frac{\alpha}{\beta} = - \left(\frac{\partial V}{\partial T} \right)_P \left(\frac{\partial P}{\partial V} \right)_T = \left(\frac{\partial P}{\partial T} \right)_V$

Since, $\left(\frac{\partial V}{\partial T} \right)_P \left(\frac{\partial T}{\partial P} \right)_V \left(\frac{\partial P}{\partial V} \right)_T = -1$ [According to cyclic Rule]

$$\text{So, } \boxed{\bar{C}_p - \bar{C}_v = \frac{\alpha^2 T V}{\beta}}$$